



MPE Series

Mounting and use

1. Select applicable cylinder model and mounting method based on actual situation :



With mounting bracket (used for MPE type)



Embedded mounting (used for MPEF type)

2. MPE series are single acting cylinders. No load is allowed at the piston rod when it is on the retraction state.

3. The force of the spring of the cylinder is for retraction of the piston rod only. The piston rod may not retract to the bottom end if there's any load.

4. Make sure the rod end lateral load is allowable. Otherwise may cause damage to the cylinder or reduce the service life.

